



ACCESSORIES & ITEMS LIST

ITEM CODE	PRODUCT NAME	SIZE	DESCRIPTION
145-8886	AutoFinish™ Crown & Bridge-Removables Media Package		AutoFinish™ media and soap package containing all necessary materials for crown & bridge dental laboratories.
145-8887	AutoFinish™ Crown & Bridge Media Package		AutoFinish™ media and soap package containing all necessary materials for crown & bridge and removable dental laboratories.
145-8885	AutoFinish™ Media, Ceramic Angled Cylinders	3/8" x 3/8", 45lb box	AutoFinish™ Media for the Cut process of dental alloys. The media effect is similar to a grinding wheel.
145-8888	AutoFinish™ Media, Plastic Pyramids	10mm, 45lb box	AutoFinish™ Media for the Refine process of dental alloys, acrylics, and 3D printed photopolymers. The media effect is similar to a rubber wheel or pumice.
145-8889	AutoFinish™ Media, Porcelain Cylinders	1.7mm x 5mm, 45lb box	AutoFinish™ Media for the Polish process of dental alloys, acrylics, 3D printed photopolymers, and zirconia. The media effect is similar to a buffing wheel.
145-8890	AutoFinish™ Media, Porcelain Spheres	2mm, 45lb box	AutoFinish™ Media for the Polish process of dental alloys, acrylics, 3D printed photopolymers, and zirconia. The media effect is similar to a buffing wheel.
145-8891	AutoFinish™ Soap 200	1gal jug	AutoFinish™ soap formulated for use on the Cut and Polish processes to aid the media in achieving the desired results for each process.
145-8893	AutoFinish™ Soap 500, Low Foam	1gal jug	AutoFinish™ soap formulated for use on the Refine process to aid the media in achieving the desired result and to keep the foam to a minimum.
145-8894	AutoFinish™ Measuring Cup	4 Tbsp	AutoFinish™ stainless steel measuring cup for accurately measuring all soaps.
145-8896	AutoFinish™ Sieve, #30 Mesh, 12"		AutoFinish™ sieve used to separate the media and the finished parts for cleaning.
145-9607	AutoFinish™ Media, Taper Pins	1/8" x 3/8", 25lb box	AutoFinish™ Media for the Support Removal process of 3D printed polyjet materials. The media effect is similar to a waterjet.
145-9608	AutoFinish™ Soap C45	1gal jug	AutoFinish™ soap formulated for use on the Support Removal process to aid the media in achieving the desired result and to eliminate foaming.

